


Water-reducible, polyester-melamine cross-linked coating

Based on Eastman™ CHDM-D



Eastman™ CHDM-D

Enamel prepared from polyester resin WS-3-2C

Features

- 57 wt% applied solids
- Excellent hardness
- Good detergent resistance
- Good stain resistance
- Good impact resistance

WS-3-2C resin formulation

Component ^a	Equivalents	Moles	Weight
Eastman™ CHDM-D	7.12	3.56	518
Trimethylolpropane	1.40	0.47	63
Phthalic anhydride	4.17	2.09	309
Adipic acid	2.78	1.39	203
		Total charge	1,093
		Water loss	-72
		Yield	1,021
No catalyst required. Nitrogen flow adequate to	o maintain <1% oxy	gen.	
^a Raw material suppliers listed on p	page 3		

Process conditions and resin properties

Up-heat rate, degree/min, from 30° to 200°C (86° to 392°F)	2
Reaction time, hours @ 200°C	2
Final acid value, mg KOH/g resin	45–55
Molecular weight, vapor pressure osmometry	600-800
Suggested dilution, % NV (see resin viscosity table)	85
Gardner™ color, 85% NV	<1
Weight/volume, 24°C (75°F), kg/L (lb/U.S. gal)	1.135 (9.48)
Final hydroxyl value	140–150

1

Water-reducible, polyester-melamine cross-linked coating Based on Eastman™ CHDM-D (Continued)

Resin viscosity (Gardner scale)

	Resin solids, wt%	
Solvent ^a	85	80
Eastman [™] <i>n</i> -butyl alcohol	Z ₅ -Z ₆	Z-Z ₁
Eastman™ EB (ethylene glycol monobutyl ether)	Z ₇	Z ₃ -Z ₄
Eastman™ DB (diethylene glycol monobutyl ether)	Z ₇ –Z ₈	Z _s

^aRaw material suppliers listed on page 3.

Enamel composition

Component	Weight	Solids
Grind ^a		
Resin WS-3-2C (85% NV)	258.0	219.3
Ti-Pure™ R-900 TiO ₂	256.3	256.3
Hexamethoxymethylmelamine	94.0	94.0
Dimethylethanolamine (DMEA)	18.1	_
Fluorosurfactant flow additive	3.1	0.3
Letdown		
Demineralized water	354.0	_
Eastman™ <i>n</i> -butyl alcohol	16.5	_

^aRaw material suppliers listed on page 3.

Enamel properties

Polyester/melamine ratio	70/30
Binder/pigment ratio	55/45
Nonvolatiles, wt%	57
Water/organic, wt%	82/18
рН	8.0-8.5
Viscosity, #4 Ford Cup, s	55–60

Water-reducible, polyester-melamine cross-linked coating Based on Eastman™ CHDM-D (Continued)

Cured film properties^{a,b}

The second secon		
Cure temperature/time, °C/min	177/20	
Gloss, 60°	98	
20°	83	
Impact resistance, N·m (inlb)		
Direct	15.8 (140)	
Reverse	10.2 (90)	
Pencil hardness	4H	
Solvent resistance, MEK double rubs	200+	
Scribed adhesion, % pass	100	
1/8 in. Conical mandrel flexibility (ASTM D522), % pass	100	
Stain resistance (ASTM D3274)	5–10	
Detergent resistance, ^c 1.5% standard detergent solution 240 h @ 74°C (165°F)		
60° Gloss retention, %	100	
Blisters, frequency/size	None	
Salt spray resistance, 500 h		
60° Gloss retention, %	100	
Scribe creepage, mm (in.)	<0.8 (<1/32)	
Blisters	None	
Storage stability		
Initial: pH/viscosity, cP	8.3/320	
After 500 h @ 120°F: pH/viscosity, cP	7.0/400	
011		

 $^{^{\}mathrm{o}}$ Unprimed, zinc phosphatized, cold-rolled steel panels coated with a 1–1½ mils (25.4–38.1 microns) film were used in these evaluations.

Raw material suppliers

Eastman [™] CHDM-D	Eastman
Ethylene glycol monobutyl ether (Eastman™ EB solvent)	Eastman
Diethylene glycol monobutyl ether (Eastman™ DB solvent)	Eastman
Eastman [™] <i>n</i> -butyl alcohol	Eastman
Ti-Pure [™] R-900 TiO ₂	DuPont
Hexamethoxymethylmelamine	Cytec
Trimethylolpropane	Geo Specialties, Perstorp
Phthalic anhydride	Stepan, Koppers
Adipic acid	DuPont

 $^{{}^{\}mathrm{b}}$ Test methods are those commonly used in the polymers and coatings industry.

 $^{{}^}c\!Coatings\ were\ applied\ over\ an\ epoxy\ primer\ for\ detergent\ resistance\ tests.$

EASTMAN

Eastman Chemical Company Corporate Headquarters

P.O. Box 431 Kingsport, TN 37662-5280 U.S.A.

Telephone:

U.S.A. and Canada, 800-EASTMAN (800-327-8626)

Other Locations, (1) 423-229-2000

Fax: (1) 423-229-1193

Eastman Chemical Latin America

9155 South Dadeland Blvd. Suite 1116 Miami, FL 33156 U.S.A.

Telephone: (1) 305-671-2800 Fax: (1) 305-671-2805

Eastman Chemical B.V.

Fascinatio Boulevard 602-614 2909 VA Capelle aan den IJssel The Netherlands

Telephone: (31) 10 2402 111

Fax: (31) 10 2402 100

Eastman (Shanghai) Chemical Commercial Company, Ltd. Jingan Branch

1206, CITIC Square No. 1168 Nanjing Road (W) Shanghai 200041, P.R. China Telephone: (86) 21 6120-8700

Fax: (86) 21 5213-5255

Eastman Chemical Japan Ltd.

MetLife Aoyama Building 5F 2-11-16 Minami Aoyama Minato-ku, Tokyo 107-0062 Japan

Telephone: (81) 3-3475-9510 Fax: (81) 3-3475-9515

Eastman Chemical Asia Pacific Pte. Ltd.

#05-04 Winsland House 3 Killiney Road Singapore 239519

Telephone: (65) 6831-3100 Fax: (65) 6732-4930

www.eastman.com

Material Safety Data Sheets providing safety precautions that should be observed when handling and storing Eastman products are available online or by request. You should obtain and review the available material safety information before handling any of these products. If any materials mentioned are not Eastman products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed.

Neither Eastman Chemical Company nor its marketing affiliates shall be responsible for the use of this information or of any product, method, or apparatus mentioned, and you must make your own determination of its suitability and completeness for your own use, for the protection of the environment, and for the health and safety of your employees and purchasers of your products. NO WARRANTY IS MADE OF THE MERCHANTABILITY OR FITNESS OF ANY PRODUCT, AND NOTHING HEREIN WAIVES ANY OF THE SELLER'S CONDITIONS OF SALE.

Eastman is a trademark of Eastman Chemical Company.
Gardner is a trademark of Byk-Gardner USA; Ti-Pure is a trademark of E.I. du Pont de Nemours and Company.

© Eastman Chemical Company, 2012.