

# Hydrogenated resin/pure monomer resin blend combinations

*as styrene-butadiene-styrene tackifiers for diaper  
construction pressure sensitive adhesives*

# Hydrogenated resin/pure monomer resin blend combinations

## as styrene-butadiene-styrene tackifiers for diaper construction pressure sensitive adhesives

### Introduction

Styrene-butadiene-styrene (SBS) polymers are commonly used in disposable diaper construction adhesives and are typically formulated with partially hydrogenated hydrocarbon resins such as Eastman's Regalite™ and Eastotac™ resins for compatibility, improved temperature resistance, thermal stability, and light color characteristics. However, due to recent availability concerns of hydrogenated hydrocarbon resins, Eastman has investigated alternative adhesive formulations using a combination of fully hydrogenated hydrocarbon resins with pure monomer resins (PMRs).

The major advantages of pure monomer resins compared to other resin chemistries include excellent thermal stability, temperature resistance (similar to or better than hydrogenated hydrocarbon resins), low molecular weight, and compatibility with SBS polymer systems when used in synergy with fully

hydrogenated hydrocarbon resins. By controlling the amount and type of resins, adhesive formulators can effectively use PMRs in combination with fully hydrogenated hydrocarbon resins to obtain performance similar to adhesives formulated solely with partially hydrogenated resins. Specifically, our tests have shown that a combination of Eastotac™ H-100W resin with a PMR resin can be used in a diaper construction PSA formulation as a replacement for partially hydrogenated resins.

Table 1 shows typical properties of selected hydrogenated hydrocarbon resins and PMRs. Values shown are an average of typical samples and should not be interpreted as product specifications.

Table 1. Typical properties of resins<sup>a</sup>

Resin	Type	Chemistry	Ring & ball softening point (°C)	Mn/Mw/Mz (Daltons)	T <sub>g</sub> (°C)	Gardner color/YID <sup>b</sup>
Regalite™ S5100	Partially hydrogenated hydrocarbon resin	Partially hydrogenated aromatic resin	97	600/900/1600	50	<1
Eastotac™ H-100W	Hydrogenated hydrocarbon resin	Fully hydrogenated aliphatic resin	100	450/1000/2150	41	<1/8
Kristalex™ 3100	PMR	Styrenic/alkyl styrenic resin	100	700/1500/2550	53	<1/5
Piccotex™ LC	PMR	Alkyl styrenic resin	91	750/1350/2200	46	<1/8
Piccolastic™ A75	PMR	Styrenic resin	74	700/1300/2250	35	1/-

<sup>a</sup> Obtained from Eastman publication WA-86A, Spectrum of Hydrocarbon Resins; WA133, Eastman Hydrocarbon resins

<sup>b</sup> YID = Yellowness Index

## Technical discussion

An SBS-based disposable diaper construction adhesive formulation was prepared with Regalite™ S5100 partially hydrogenated hydrocarbon resin as the control. The effects of three different PMRs (Kristalex™ 3100, Piccotex™ LC, and Piccolastic™ A75) in combination with Eastotac™ H-100W

fully hydrogenated hydrocarbon resin were evaluated at two different extension amounts; 12% by weight and 18% by weight in formulation, which equates to 20% and 30% PMR with respect to total resin amount (Eastotac™ H100W:PMR, 80:20 and 70:30 ratios). Table 2 shows the formulations used in this study.

**Table 2.** Disposable diaper construction adhesive formulations with PMRs

Materials wt%	Regalite™ S5100 control	Kristalex™ 3100		Piccotex™ LC		Piccolastic™ A75	
		80:20 H100W:3100	70:30 H100W:3100	80:20 H100W:LC	70:30 H100W:LC	80:20 H100W:A75	70:30 H100W:A75
Kraton™ 1102 <sup>a</sup>	20	20	20	20	20	20	20
Regalite™ S5100 <sup>b</sup>	59.5	-	-	-	-	-	-
Eastotac™ H-100W <sup>b</sup>	-	47.5	41.5	47.5	41.5	47.5	41.5
Kristalex™ 3085 <sup>b</sup>	-	12	18	-	-	-	-
Piccotex™ LC <sup>b</sup>	-	-	-	12	18	-	-
Piccolastic™ A75 <sup>b</sup>	-	-	-	-	-	12	18
Calsol™ 5550 <sup>c</sup>	20	20	20	20	20	20	20
Irganox™ 1010 <sup>d</sup>	0.5	0.5	0.5	0.5	0.5	0.5	0.5

<sup>a</sup>KRATON Polymers LLC (polymer)

<sup>b</sup>Eastman Chemical Company (resins)

<sup>c</sup>Calumet Specialty Products (naphthenic oil)

<sup>d</sup>BASF (antioxidant)


Formulations were prepared utilizing a Brabender mixer and evaluated for the following:

- Viscoelastic properties—Using Dynamic Mechanical Analysis (DMA)
- Viscosity profiles at different temperatures (before and after aging [177°C for 72 h])—Brookfield viscometer

- Adhesive property evaluation—1-mil-thick adhesive coating on Mylar™
  - 180 degree peel on stainless steel substrate (peel rate @ 4 inches/min)
  - Loop tack on stainless steel substrate

Figures 1a and 1b show the viscoelastic performance analysis of the Eastotac™ PMR combination formulations at two different levels, along with the partially hydrogenated hydrocarbon resin (Regalite™ S5100) control formulation.


**Figure 1.** Viscoelastic properties of formulations with Eastotac™/PMR combinations



As can be seen in Figure 1b, 70:30 blends of Eastotac™ H100W and Piccotex™ LC resin and 70:30 blends of Eastotac™ H100W and Kristalex™ 3100 resin formulations showed the most comparable  $T_g$  and elastic modulus to the control formulation. The single  $T_g$  of the Eastotac™/PMR resin combination formulation is an indication of compatibility with the SBS polymer. All of the 80:20 Eastotac™/PMR resin containing formulations showed slightly different viscoelastic characteristics than the control.

Figure 2 shows the absolute values of important parameters such as  $T_g$ ,  $\tan \delta$  minimum value at  $\tan \delta$  minimum temperature (an indication of cohesive property), 3rd crossover temperature (indication of melting temperature), and  $\tan \delta$  peak value at  $T_g$  (indication of tack). As can be seen from Figure 2, 70:30 blends of Eastotac™ H100W and Piccotex™ LC and 70:30 blends of Eastotac™ H100W and Kristalex™ 3100 formulations showed the most comparable  $T_g$ ,  $\tan \delta$  minimum temperature,  $\tan \delta$  peak value and 3rd crossover temperatures. Figures 3 and 4 show the adhesive property evaluation results, which were performed with 0.9–1-mil-thick Mylar-coated films on a stainless steel substrate.

Figure 2. Viscoelastic property comparison values from DMA



Figures 3 and 4 show the 180 degree peel adhesion loop tack results on a stainless steel substrate respectively. A combination of 20% PMR with Eastotac™ H100W resins shows lower adhesive peel and loop tack compared to the control formulation. However, a combination of 30% PMR with Eastotac™ H100W resin shows comparable adhesive peel but lower loop tack compared to the control formulation. The lower tack performance may be due to the structural differences between Regalite™ S5100 and Eastotac™ H100W/PMR combination resins. In the case of Regalite™ S5100, aliphatic and aromatic moieties are within one chain backbone compared to the fully hydrogenated/PMR resin combinations, which are a physical

blend of aliphatic and aromatic moieties. Even though fully hydrogenated/PMR resin combination-based formulations exhibit similar viscoelastic characteristics compared to the control formulation, the combination of resins may have some macrophase separation limiting the total molecular mobility of the chains which results in lower loop tack. However, it should be noted that tack is not an important criterion for diaper construction adhesives, since it is mostly a one-time adhesive application process (no bonding and debonding as in PSA tapes or labels, where tack is very important).

Figure 3. 180 degree peel on stainless steel (peel rate at 4 inches/min)






Figure 4. Loop tack on stainless steel



As can be seen from the viscosity profiles (Figure 5) at five different temperatures, the viscosity characteristics for Eastotac™/PMR resin combination formulations at both PMR levels (20% and 30%) are similar or comparable to the control formulation, even after aging at 177°C for 72 h.

**Figure 5. Brookfield viscosity (cps) profiles of formulations at different temperatures**



**Figure 6. Aging studies of the formulations at 177°C for 72 h**




Figure 6 shows the pictures of the formulation before and after aging. Aging was performed in an air-drafted oven at 177°C for 72 h.

As clearly depicted in Figure 6, the before and after aging characteristics, especially in regards to color, for the Eastotac™/PMR combination resin formulations are similar or better than the control formulation.

## Conclusion

The combination of fully hydrogenated hydrocarbon resins such as Eastotac with a pure monomer resin can be used as a tackifier in SBS-based adhesives used in nonwoven PSA formulations as a replacement for partially hydrogenated resins.

- 70:30 Eastotac™ H100W:Piccotex™ LC combination and 70:30 Eastotac™ H100W:Kristalex™ 3100 resin combination showed the most comparable performance.
  - Similar viscoelastic characteristics and adhesive peel
  - Good thermal stability on aging—both color & viscosity stability



**Eastman Chemical Company  
Corporate Headquarters**

P.O. Box 431  
Kingsport, TN 37662-5280 U.S.A.

Telephone:  
U.S.A. and Canada, 800-EASTMAN (800-327-8626)  
Other Locations, (1) 423-229-2000  
Fax: (1) 423-229-1193

**Eastman Chemical Latin America**

9155 South Dadeland Blvd.  
Suite 1116  
Miami, FL 33156 U.S.A.

Telephone: (1) 305-671-2800  
Fax: (1) 305-671-2805

**Eastman Chemical B.V.**

Fascinatio Boulevard 602-614  
2909 VA Capelle aan den IJssel  
The Netherlands

Telephone: (31) 10 2402 111  
Fax: (31) 10 2402 100

**Eastman (Shanghai) Chemical  
Commercial Company, Ltd. Jingan Branch**

1206, CITIC Square  
No. 1168 Nanjing Road (W)  
Shanghai 200041, P.R. China

Telephone: (86) 21 6120-8700  
Fax: (86) 21 5213-5255

**Eastman Chemical Japan Ltd.**

MetLife Aoyama Building 5F  
2-11-16 Minami Aoyama  
Minato-ku, Tokyo 107-0062 Japan

Telephone: (81) 3-3475-9510  
Fax: (81) 3-3475-9515

**Eastman Chemical Asia Pacific Pte. Ltd.**

#05-04 Winsland House  
3 Killiney Road  
Singapore 239519

Telephone: (65) 6831-3100  
Fax: (65) 6732-4930

[www.eastman.com](http://www.eastman.com)

Although the information and recommendations set forth herein are presented in good faith, Eastman Chemical Company makes no representations or warranties as to the completeness or accuracy thereof. You must make your own determination of its suitability and completeness for your own use, for the protection of the environment, and for the health and safety of your employees and purchasers of your products. Nothing contained herein is to be construed as a recommendation to use any product, process, equipment, or formulation in conflict with any patent, and we make no representations or warranties, express or implied, that the use thereof will not infringe any patent. NO REPRESENTATIONS OR WARRANTIES, EITHER EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OF ANY OTHER NATURE ARE MADE HEREUNDER WITH RESPECT TO INFORMATION OR THE PRODUCT TO WHICH INFORMATION REFERS AND NOTHING HEREIN WAIVES ANY OF THE SELLER'S CONDITIONS OF SALE.

Material Safety Data Sheets providing safety precautions that should be observed when handling and storing our products are available online or by request. You should obtain and review available material safety information before handling our products. If any materials mentioned are not our products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed.

© 2012 Eastman Chemical Company. Eastman, Eastotac, Kristalex, Piccolastic, Piccotex, and Regalite are trademarks of Eastman Chemical Company. Mylar is a trademark of DuPont Teijin Films. Kraton is a trademark of KRATON Polymers, LLC. Calsol is a trademark of Calumet Specialty Products. Irganox is a trademark of BASF.