Sustained heat transfer fluid performance



Conrad Gamble, P.E. Sr. Technical Specialist Eastman



Why is it important?

Heat transfer fluids (HTFs) are necessary in many processes.

- Over time, fluid can deviate from optimal performance. This can lead to increases in:
 - Energy use/costs
 - Unplanned downtime/maintenance

The Eastman Therminol white paper

"Optimize Heat Transfer Fluid Performance:

How to Avoid Costly Consequences"

shares more about how to establish good performance. (See Therminol.com>Resources>System Maintenance Resources)

- Today's session can help you learn how to:
 - Sustain performance of heat transfer fluids
 - Slow the onset of deterioration effects



3 key threats to heat transfer fluid

Changes in fluid quality

- **Composition**: Degradation outpaces fresh fluid addition benefits
- Physical properties
 - Liquid density
 - Viscosity
 - Heat capacity
 - Thermal conductivity
 - Insoluble solids content
 - Acidity
 - Fire properties

Changes in ability to meet process requirements

- Revised process conditions, new/modified circuits, or new operating units
- Changes in heat transfer efficiency
 - Impacts to heat transfer coefficient and system fouling potential

Understanding potential threats helps when developing a protection strategy against adverse fluid changes.

THERMINOL

Fluid quality indicators

Composition

Can deviate by:

Oxidation and thermal stresses

- Organic acids and solids formation from fluid oxidation
- Degradation products accumulation from thermal degradation
- Fluid mixing, venting, replacement, and make-up fluid addition
 - Changes from published new-fluid properties occur as a result of thermal degradation, venting capability, and fresh make-up fluid addition rates, as well as from contamination events (in-leakage, improper make-up fluid addition).

Identify and establish protection against causes of excessive oxidation and thermal stresses and maintenance impacts to the fluid.





Fluid quality indicators

Physical properties

Can deviate due to:

Oxidation

- Viscosity
- Solids
- Fouling
- Corrosion
- Thermal stresses at heat source(s)
 - Time and temperature dependent

Contamination

THERMINOL

- Process leaks
- Wrong make-up fluid

Can affect:

- Viscosities
 - Low and high temperature
- Liquid density
- Vapor pressure
- Boiling point
- Pump cavitation risk
- Flash point
 - Lowest temperature at which vapors can ignite in air



Fluid quality indicators

Color

- Some fluid changes from use are apparent but have no direct impact on performance.
- Color is only an indirect indicator of fluid quality.
- Atypical color may be an indicator of:
 - Premature aging or contamination; high moisture content
 - Requires fluid analysis of key parameters to assess
- Dark fluid color can be a normal characteristic based on service conditions.

Odor

- Fluids will have typical odors based on their chemistry.
- Changes can result from stresses and contamination.
- Fluid analysis is required to properly assess fluid quality.



HTF properly matched with needs Part 1


Fluid to meet process heat duty and temperatures

- Sustained performance within design constraints of the system
- Safe, ongoing compatibility
- Meets low- and high-temperature demands

System design to support fluid quality maintenance

Ability to:

- Remove excess moisture
- Remove low-boiling degradation products
- Add make-up fluid
- Provide for insoluble solids removal
- Protect the fluid from detrimental oxidation




B.O.S.S 1000 Fluid Sampling Station is a trademark of Heat Exchange & Transfer, Inc.





Expansion tank design for fluid management





HTF properly matched with needs Part 2

• Proper HTF storage

- Bulk—storage vessels protected from oxidation and moisture condensation
- Drums—store indoors on sides in drum racks, or use drum covers

• Proper reuse, removal, and disposal

- Safely protect fluid handling during system downtimes (e.g., turnarounds).
- Ability to properly remove and add fluid; complete removal with minimal 'heel'
- Comply with jurisdictional requirements for used fluid disposal management.



Key threats to HTF performance

Oxidation

- Increases viscosity and acidity
- Use static pad of inert gas for protection.

Thermal stress/degradation

- Time and temperature dependent
- Avoid high-temperature excursions.
- Refer to NFPA 87 Standard for fluid heaters.

Contaminants

THERMINOL

- HTX design (strength-welded tube connections)
- Avoid mixing fluids.
- Do not reuse vent condensate.
- Use correct make-up fluids.


Lack of fluid monitoring

Basic stewardship of HTF includes:

- No/low-cost sample analysis
- Trending of quality parameters
- Establish relationship with the HTF manufacturer's rep and use their expertise.

Change in fluid-side heat transfer coefficient, *h* with viscosity

% Increase in kinematic viscosity



For heat transfer fluid within round conduit and turbulent flow



Monitoring of performance

Fluid

- Stable temperatures over time
 - Heater outlet, process users
- Energy efficiency
 - Heater and process users
 - Pressure drop
- Key HTF quality parameters

Monitor the following with help from fluid manufacturer:

- Viscosity
- Acid number
- Moisture
- Solids
- Degradation products
- Flash point

Process

- Key process indicators
 - Batch times
 - Heat-up times
 - Low-temperature start-up
 - Pressure drops
 - Temperatures at heat exchangers
- Operation symptoms
 - Cavitation
 - Excessive venting
 - Gurgling sounds
- Equipment
 - Corrosion
 - Fluid leakage
 - Pump seal failures
 - Instrument tubing plugging
 - Difficulty starting pumps in low temperatures

EASTM



Monitoring heat transfer fluid

Sample HTF the first month and annually thereafter.

12

Monitor key indicators:

- Viscosity
- Acid number
- Moisture

THERMINOL

- Solids
- Degradation products

Compare analysis results to normal/expected results.

- On track? Problems?
- Utilize expertise available from the fluid manufacturer

Consider causes of trends and take actions to correct.

- Example #1—A case of no action taken
- Example #2—Proactive response extends fluid life



Monitoring system features*

Examples

Heat sources—heater, WHRU, and electric heater Monitoring to include:

- % excess air
- Soot/ash
- Pressure drop
- Coil skin temperature
- Burner vibration

- Stack gas temperature
- Flame appearance
- Flow rate each pass
- Coil temperature profile
- Damper positions

Inert gas supply—typically nitrogen

Monitoring to include:

- Gas purity
- Valve alignment
- Spare cylinders

- Supply pressure OK
- No constant purge
- Check valve in service
- Pumps—commonly centrifugal, but can vary

Monitoring to include:

- Vibration
- Shaft alignment
- MFR PM checks

- Seal leakage
- Cavitation
- Spare pump readiness
- * This is not a comprehensive list.
- ** MFR: manufacturer
- *** PM: preventive maintenance

- Fire box temperature
- Temperature rise
- Heater skin temperature
- Fuel usage
- MFR** PM*** checks
- Regulated pressure OK
- Back-pressure regulator working

• Barrier seal pot level/pressure

- Lubrication
- Flow rate stability



Action plan

- Establish site goal.
 - Implement a plan to expand on the information provided.
 - Make it site specific with exact make/model equipment used.
- Train essential personnel to assume ownership of the monitoring plan.
- Take initial baseline readings.
- Refine plan as needed.
- Encourage action when deviations are observed.
- Report observations, actions taken, and results obtained.

Enjoy the benefits of implementing this routine!







For more information, visit Therminol.com.

Although the information and recommendations set forth herein are presented in good faith, Eastman Chemical Company ("Eastman") and its subsidiaries make no representations or warranties as to the completeness or accuracy thereof. You must make your own determination of its suitability and completeness for your own use, for the protection of the environment, and for the health and safety of your employees and purchasers of your products. Nothing contained herein is to be construed as a recommendation to use any product, process, equipment, or formulation in conflict with any patent, and we make no representations or warranties, express or implied, that the use thereof will not infringe any patent. NO REPRESENTATIONS OR WARRANTIES, EITHER EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OF ANY OTHER NATURE ARE MADE HEREUNDER WITH RESPECT TO INFORMATION OR THE PRODUCT TO WHICH INFORMATION REFERS AND NOTHING HEREIN WAIVES ANY OF THE SELLER'S CONDITIONS OF SALE. Safety Data Sheets providing safety precautions that should be observed when handling and storing our products are available online or by request. You should obtain and review available material safety information before handling our products. If any materials mentioned are not our products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed. © 2018 Eastman. Eastman brands referenced herein are trademarks of Eastman or one of its subsidiaries or are being used under license. The ® symbol denotes registered trademark status in the U.S.; marks may also be registered internationally. Non-Eastman brands referenced herein are trademarks of their respective owners.

©2018 Eastman Chemical Company. Eastman brands referenced herein are trademarks of Eastman or one of its subsidiaries or are being used under license. The ® symbol denotes registered trademark status in the U.S.; marks may also be registered internationally. Non-Eastman brands referenced herein are trademarks of their respective owners.

Email: team.Therminol@eastman.com

EASTMAN

