

## Creamy, strong-hold pomade with Eastman AQ™ 48 ultra polymer and Eastman Sustane™ SAIB

Part	Product name	Wt%	Ingredient/INCI name	Manufacturer
A	Deionized water	46.45	Water (aqua)	—
	Glycerin	5.00	Glycerin	—
	D-Panthenol	0.10	Panthenol	DSM
	Eastman AQ™ 48 ultra polymer	8.00	Polyester-5	Eastman
	Dermofeel™ PA-12	0.05	Sodium phytate	Evonik-Dr. Straetmans
	Aloe Vera Extract 10X	0.20	Aloe barbadensis (aloe) leaf juice	Terry Laboratories
B	Eastman Sustane™ SAIB MCT	10.00	Sucrose acetate isobutyrate (and) caprylic/capric triglyceride	Eastman
	Lipocol™ SC-20	5.00	Cetareth-20	Vantage
	Lipocol™ SC-1618	6.00	Cetearyl alcohol	Vantage
	SIMULSOL™ 165	6.00	Glyceryl stearate (and) PEG-100 stearate	SEPPIC
	Beeswax	3.00	Beeswax (cera alba)	Strahl & Pitsch
	Candelilla wax	1.00	Euphorbia cerifera (candelilla) wax	—
	Lipocol™ HCO-40	1.00	PEG-40 hydrogenated castor oil	Vantage
	TEGOSOFT® DCE	2.00	Diethylhexyl carbonate	Evonik Industries
	Lipex Shea™	1.00	Butyrospermum parkii (shea) butter	AAK
	Lipovol™ ALM	1.00	Prunus amygdalus dulcis (sweet almond) oil	Vantage
SOFTISAN® 378	1.00	Caprylic/capric/myristic/stearic triglyceride	IOI Oleo	
C	KEM CP	1.00	Phenoxyethanol (and) chlorphenesin (and) ethylhexylglycerin	Akema
	Butylene glycol	2.00	Butylene glycol	Dow
	Sodium hydroxide 50%	0.20	Sodium hydroxide	—

*continued on back »*

## PROCEDURE

1. Weigh out part A into a clean, sanitized stainless steel vessel, and heat it to 80°–85°C.
2. Make sure that part A is clear and all ingredients are completely dispersed before moving on. Mix with scrapers.
3. Weigh out part B into a clean, sanitized stainless steel vessel, and heat it to 70°–75°C.
4. Slowly add part B to part A while mixing. Make sure that the temperature doesn't go below 75°C.
5. Once homogeneous, add part C.
6. Pour temperature is between 50°–55°C.
7. Adjust pH\* if required.

\*pH @ 25°C: 5.5–6.5

---

**EASTMAN**  
The results of **insight**™

**Eastman Corporate Headquarters**  
P.O. Box 431  
Kingsport, TN 37662-5280 U.S.A.

U.S.A. and Canada, 800-EASTMAN (800-327-8626)  
Other Locations, +(1) 423-229-2000

[www.eastman.com/locations](http://www.eastman.com/locations)

Although the information and recommendations set forth herein are presented in good faith, Eastman Chemical Company ("Eastman") and its subsidiaries make no representations or warranties as to the completeness or accuracy thereof. You must make your own determination of its suitability and completeness for your own use, for the protection of the environment, and for the health and safety of your employees and purchasers of your products. Nothing contained herein is to be construed as a recommendation to use any product, process, equipment, or formulation in conflict with any patent, and we make no representations or warranties, express or implied, that the use thereof will not infringe any patent. NO REPRESENTATIONS OR WARRANTIES, EITHER EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OF ANY OTHER NATURE ARE MADE HEREUNDER WITH RESPECT TO INFORMATION OR THE PRODUCT TO WHICH INFORMATION REFERS AND NOTHING HEREIN WAIVES ANY OF THE SELLER'S CONDITIONS OF SALE.

Safety Data Sheets providing safety precautions that should be observed when handling and storing our products are available online or by request. You should obtain and review available material safety information before handling our products. If any materials mentioned are not our products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed.

© 2020 Eastman. Eastman brands referenced herein are trademarks of Eastman or one of its subsidiaries or are being used under license. The ® symbol denotes registered trademark status in the U.S.; marks may also be registered internationally. Non-Eastman brands referenced herein are trademarks of their respective owners.